

Thermal Binding Machine T30

Operating Instruction

Thank you for choosing T30 Thermal binding machine, it's a smart method for binding your documents: easy and elegant! We mightily suggest you to read this operating instruction carefully before first use.



Installation

1. Cooling shelf: there are mounting holes in the bottom of T30, insert the cooling shelf in the mounting holes by pushing with some force.
2. Keep machine away from direct sunshine, always place T30 in room temperature.

Operating

1. Choose a suitable thermal cover and ensure papers/document sheets are flush at each edge.
2. Turn on T30, pre-heat about 1 minutes.
3. When green light on, it's ready for heating, put the cover on the heated groove (Caution: Ensure all papers are flush at each edge!)
4. 10 seconds after yellow light on with buzzer, take out the cover and put it on the cooling shelf.
5. Two minutes cool down, complete the binding operating.

Warning

1. Ensure papers are exactly flush in the thermal cover before put into the binding slot.
2. Do not overload papers into the cover.
3. Keep the heating slot clean.

Instruction of thermal cover/papers(70-80g)

Item	1mm	2mm	3mm	4mm	6mm	8mm	10mm
Paper	<10	<20	<30	<40	<60	<80	<100
Item	12mm	15mm	18mm	20mm	22mm	24mm	
Paper	<120	<150	<180	<200	<220	<240	

Technical Data

Power: 220V or 110V/60W

Working temperature: 145±5°C

Net Weight: 1.7kgs

DIM: 39x19x17.5cm